


Update Instructions

The following procedure is used for updating the firmware for the AT-HDVS-150-TX-WP. This process applies to both the AT-HDVS-150-TX-WP-US and AT-HDVS-150-TX-WP-UK models.

Requirements


- AT-HDVS-150-TX-WP-US or AT-HDVS-150-TX-WP-UK
- Firmware file: AT-HDVS-150-TX_[version].bin
- USB Type A to Mini-USB Type B cable
- Computer with USB port

1. Download the latest firmware from the Atlona web site.
2. Remove the AT-HDVS-150-TX-WP from the wall, or other surface, by removing the four screws from the front of the wall plate.
3. Disconnect the power to the AT-HDVS-150-TX-WP by disconnecting the Ethernet cable from the **HDBaseT OUT** port on the AT-HDVS-150-TX-WP.
4. Remove the faceplate from the front of the AT-HDVS-150-TX-WP, by unscrewing the two locking connectors for the **VGA IN** port and the locking connector for the **HDMI IN** port, using a small hex driver or pliers.




Update Instructions

- Press and hold the **DISPLAY ON/OFF** button, while connecting the USB cable from the computer to the mini-USB port on the AT-HDVS-150-TX-WP.



- After a few seconds, a folder with the name USB UPDATER, will be displayed. Release the **DISPLAY ON/OFF** button.

If the folder is not displayed, open Windows Explorer and locate the drive named USB UPDATER.



- Delete all files from the USB drive, if any are present.
- Drag-and-drop the AT-HDVS-150-TX_[version].bin firmware file to the drive.
- After the file has been copied, disconnect the USB cable from both the computer and the AT-HDVS-150-TX-WP.
- Reconnect the Ethernet cable to the HDBaseT OUT port on the AT-HDVS-150-TX-WP.
- The firmware update process is complete.
- Attach the faceplate then reinstall the AT-HDVS-150-TX-WP.